		WBG-V Load-ring Vario							WBG-Load-ring																	VRS Starpoint Vario eyebolt									RS/RM high-tensile eyebolt, eyenut											RBG Load-ring					
		Page 10							Page 11																	Page 14									Page 16											Page 18					
LBG(3) M16 RS 1t	LBG(3) M20 RS	WBG-V-0,3 t	WBG-V-0,45 t	WBG-V-0,6 t	WBG-V-1,3 t	WBG-V-2 t	WBG-V-3,5 t	WBG-V-5 t	WBG 6 t	WBG 8 t	WBG 8-Sond.	WBG 10 t	WBG 10 t	WBG 10-Sond.	WBG 15 t	WBG 15 t	WBG 15-Sond.	WBG 25 t	WBG 30 t	WBG 35 t	WBG 35-Sond.	VRS-M 8	VRS-M10	VRS-M12	VRS-M16	VRS-M20	VRS-M24	VRS-M30	VRS-M36	VRS-M42	VRS-M48	RS-M6	RS-M8	RS-M10	RS-M12	RS-M14	RS-M16	RS-M20	RS-M24	RS-M30	RS-M36	RS-M42	RS-M48	RBG 3	RBG 8	RBG 15 t	RBG 30 t	RBG 50 t	RBG 80 t
M 16	M 20	M 8	M 10	M 12	M 16	M 20	M 24	M 30	M 33	M 36	M 39	M 42	M 48	M 42-52	M 56	M 64	M 56-85	M 72-76	M 80-85	M 90	M 90-150	M 8	M 10	M 12	M 16	M 20	M 24	M 30	M 36	M 42	M 48	M 6	M 8	M 10	M 12	M 14	M 16	M 20	M 24	M 30	M 36	M 42	M 48	2x M 16	4x M 20	4x M 30	6x M 36	8x M 36	–
1	2	0,6	0,9	1,2	2,6	4	7	10	12,5	12,5	12,5	16	16	16	25	25	25	35	35	35	35	0,8	1	2	4	6	8	12	16	24	32	0,4	0,8	1	1,6	3	4	6	8	12	16	24	32	3	8	15	30	50	80
2	4	1,2	1,8	2,4	5,2	8	14	20	25	25	25	32	32	32	50	50	50	70	70	70	70	1,6	2	4	8	12	16	24	32	48	64	0,8	1,6	2	3,2	6	8	12	16	24	32	48	64	6	16	30	60	100	160
1	2	0,3 (0,4)	0,4 (0,6)	0,6 (0,7)	1,3 (1,5)	2 (2,5)	3,5 (4)	5 (6)	6 (7,5)	8 (10)	8 (10)	10 (12,5)	10 (12,5)	10 (12,5)	15 (18)	15 (18)	15 (18)	25 (30)	30 (35)	35	35	0,4	0,4	0,7	1,5	2,3	3,2	4,5	7	9	12															3	8	15	30	50	80
2	4	0,6 (0,8)	0,9 (1,2)	1,2 (1,5)	2,6 (3)	4 (5)	7 (8)	10 (12)	12 (15)	16 (20)	16 (20)	20 (25)	20 (25)	20 (25)	30 (36)	30 (36)	30 (36)	50 (60)	60 (70	70 (80)	70 (80)	0,8	0,8	1,5	3	4,6	6,4	9	14	18	24													6	16	30	60	100	160
1,4	2,8	0,4	0,6	0,8	1,8	2,8	4,9	7	8,4 (10,5)	11,2 (14)	11,2 (14)	14 (17,5)	14 (17,5)	14 (17,5)	21 (25,6)	21 (25,6)	21 (25,6)	35 (42)	42 (49)	49 (56)	49 (56)	0,56	0,5	1	2,1	3,2	4,5	6,3	9,8	12,6	16,8													4,2	11,2	21	42	70	112
1	2	0,3	0,4	0,6	1,3	2	3,5	5	6 (7,5)	8 (10)	8 (10)	10 (12,5)	10 (12,5)	10 (12,5)	15 (18)	15 (18)	15 (18)	25 (30)	30 (35)	35 (40)	35 (40)	0,4	0,4	0,7	1,5	2,3	3,2	4,5	7	9	12													3	8	15	30	50	80
1	2	0,3	0,4	0,6	1,3	2	3,5	5	6 (7,5)	8 (10)	8 (10)	10 (12,5)	10 (12,5)	10 (12,5)	15 (18)	15 (18)	15 (18)	25 (30)	30 (35)	35 (40)	35 (40)	0,4	0,4	0,7	1,5	2,3	3,2	4,5	7	9	12													3	8	15	30	50	80
2,1	4,2	0,6	0,9	1,2	2,7	4,2	7,3	10,5	12,6 (15,7)	16,8 (21)	16,8 (21)	21 (26,2)	21 (26,2)	21 (26,2)	31,5 (38)	31,5 (38)	31,5 (38)	52,5 (63)	63 (73,5)	73,5 (84)	73,5 (84)	0,8	0,8	1,6	3,1	4,8	6,7	9,4	14,7	18,9	25,2													6,5	16,8	31,5	63	105	168
1,5	3	0,4	0,6	0,9	1,9	3	5,2	7,5	9 (11,2)	12 (15)	12 (15)	15 (18,8)	15 (18,8)	15 (18,8)	22,5 (27)	22,5 (27)	22,5 (27)	37,5 (45)	45 (52,5)	52,5 (60)	52,5 (60)	0,6	0,6	1,1	2,2	3,4	4,8	6,7	10,5	13,5	18													4,5	12	22,5	45	75	120
1	2	0,3	0,4	0,6	1,3	2	3,5	5	6 (7,5)	8 (10)	8 (10)	10 (12,5)	10 (12,5)	10 (12,5)	15 (18)	15 (18)	15 (18)	25 (30)	30 (35)	35 (40)	35 (40)	0,4	0,4	0,7	1,5	2,3	3,2	4,5	7	9	12													3	8	15	30	50	80
100	200	Serrare saldamente																				Hand tight																					120	200	600	900	1000	

Si raccomanda di usare sia il "VRS Starpoint" che il "PowerPoint" in modo che possano essere regolati verso la direzione di tiro!